pocket operator
overview
[en]

pocket operator

selected tempo

time / info

sound parameters A / B

sound

pattern

knob A / B

bpm

sound   pattern   bpm *m*

1   2   3   4   funct   function

5   6   7   8   FX   effects

sound 1-16
pattern 1-16
effects 1-16

9   10   11   12   play   play / stop

13   14   15   16   write   write ◻

1. start the sequencer
   press [play]

2. choose pattern
   hold [pattern] and press [1-16]

3. set tempo
   press [bpm] to toggle (80 / 120 / 140)
   or hold [bpm] and turn [B]

4. edit pattern - step write
   press [write] to light the write symbol (◻)
   press [1-16] to place triggers

5. edit pattern - tap write
   press [write] to deselect write (◻ should *not* be visible)
   press and hold [write] and press [1-16] to record live

6. add effects
   press and hold [FX] and hold [1-16]