

GK-49 Size Chart

Akai	MPK 61	MPK261								
Alesis	FUSION 6HD	ION	QS6.2	VI49	VORTEX	VX49 - 49-key USB MIDI Controller				
Arturia	KeyLab 49	KeyLab 61	KeyLab mkII 49	KeyLab mkII 61						
Behringer	DeepMind 12									
Casio	AT3	CTK-2000	CTK-2100	CTK-2550	CTK-3000	CTK-3200	CTK-3500	CTK-4000	CTK-4200	CTK-496
	CTK-5000	CTK-6000	CTK-7000	CTK-710	CT-X700	LK-100	LK-165	LK-175	LK-200S	LK-220
	LK-230	LK250	LK-260	LK-270	LK-280					
Clavia	NORD ELECTRO 2 61	NORD ELECTRO 61	NORD LEAD 2	NORD LEAD 2X	NORD LEAD 3					
CME	UF5	UF50	VX 5							
Dave Smith	Prophet 08	Prophet 6								
E-MU	SHORTboard 49									
Hammond	SK1									
Korg	Kross 2 61	Kross 2 61-Key	Kross 61	micro ARRANGER	microPIANO	PS60				RK-100S
Kurzweil	PC161									
M-Audio	AXIOM 49	Axiom Pro49	Venom							
Nektar	Impact LX61	Panorama P4								
Nord	ELECTRO 2 61	ELECTRO 3 61	Electro 4D SW61	Electro 5D 61	Electro 6D 61	Lead 4	Nord Lead 2X	Nord Wave		
Novation	49 SL Mk II	61 SL Mk II	Impulse49	Launchkey 49	Launchkey 61	REMOTE49	REMOTE49 SLC	XSTATION 49		
Roland	JP-8000	SH-201	VP-550	VP-770						
StudioLogic	SL161PRO	VMK149	VMK-161+	VMK-161+ORGAN						
Suzuki	SP-37	SP-67								
Yamaha	EZ150	EZ200	EZ220	EZ250I	KX49	KX61	MM6	MX49	PSR 175	PSR-172
	PSR-273	PSR-E203	PSR-E213	PSR-E223	PSR-E233	PSR-E253	PSR-E263	PSR-E303	PSR-E313	PSR-E323
	PSR-E333	PSR-E353	PSR-E363	PSR-E433	PSR-F51	YPT-200	YPT-220	YPT-255	YPT-310	