

GKB-61 Size Chart

Korg	Pa300	Pa4X-61	Pa600	X3						
Kurzweil	K2661	PC361	PC3A6	PC3K6	PC3LE6					
Moog	Voyager XL									
Roland	FANTOM X6	FANTOM XA 61	GW-8	JV30	Prelude	XP-50				
Sequential	Prophet X									
Studiologic	SL73	Sledge								
Suzuki	SP-37	SP-67								
Yamaha	EZ200	EZ220	MM6	MO6	MOTIF XF6	MOTIF XS6	MOX6	MOXF6	PSR-E223	PSR-E233
Yamaha	PSR-E253	PSR-E323	PSR-E353	PSR-E363	SY77	YPT-200	YPT-220	YPT-255		